

### SuperTag Hand Held Detacher

A portable unit, the Hand Held Detacher is especially useful for removing SuperTags from bulky items such as winter coats or items where a lanyard has been used. Taking the Detacher to the item rather than having to take the item to the Detacher. The unit is also useful as a back-up to a Power Detacher in the event of a power failure.

Securing the detacher at the point of sale is important. A high strength cable is fitted to the Detacher handle which should be affixed to the counter at the point of sale. The lock at the side of the detacher allows the unit to be secured when there is no member of staff at the point of sale. These keys should be held securely in the store. For additional security a Sensormatic Tag is incorporated into the Detacher causing the Pedestals at the exit to alarm if anyone tries to remove the detacher from the store.



### How to Use the SuperTag Hand Held Detacher

To remove a SuperTag.



1. Hold the **Detacher** firmly in one hand and the tagged item in the other by the **Tag**.



2. Holding the tagged item near the **Pin** with the **Tag** free and clear of the garment, place the **Tag** in the **Detacher**, thick end first at a slight downward angle.



3. Push the **Tag** down to the horizontal position, **then** squeeze the trigger.



4. Holding the trigger, separate the **Pin** and item from the **Tag**.

5. Remove the **Pin** from the garment. Release the trigger and remove the **Tag** from the **Detacher**.

**IMPORTANT:** Ensure the **Pin** and **Tag** are stored separately at the point of sale.

Consistent placement of the Tags on items of clothing ensures the Tag is placed in the most secure position and allows them to be found quickly at the point of sale. This makes the detaching process simpler - see Sensormatic's **Tag Placement Guide** for details.